













|   |  |   |
|---|--|---|
| (1)X1   | (2)X1  | (3)X1 (L)X1 (R)   |
|    |   |  |
| BACK  | SEAT   | LARM LEFT ARM<br>RARM RIGHT ARM   |
| (4)X1   | (5)X1  | (6)X1   |
|    |   |  |
| MECHANISM   | GAS LIFT   | BASE  |
| (7)X5   | <div>(A)x4  M8*22 Mechanism Screw</div> <div>(B)x4  M8*45 ARM SCREW</div> <div>(C)x4  M6*30 L-Bar Screw</div> <div>(D)x4  ARM CAP</div> <div>(E)x1  ALLEN KEY</div> |   |
|  | CASTERS  |   |

Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.

